

# QuikHold

## Installation

### 4 Steps to adhere traffic control devices

#### Step 1

Peel Stick & Heat. Begin by removing the white wax paper from the bottom side of the pad and discard properly



#### Step 2

After removal of the white wax paper, press the exposed side onto the surface where the reflector is to be located



#### Step 3

Heat the top of the Quik Pad using either a standard torch pad is liquefied and the clear plastic is flashed off



#### Step 4

Immediately press device on softened Pad and allow cooling, to achieve maximum adhesion requires only a few minutes.



*As with all sealant materials, contacting surfaces must be completely clean, dry and free of foreign and loose materials. When used for repairing cuts in existing pavements, openings should be squarely and*

**Caution! Do not allow material to come into contact with skin when in a hot liquefied state**

**Quik Pave Products Inc.**

www.quikpave.com  
7968 Wesselman  
Rd  
Cleves Ohio 45002  
U.S.A

Tel. 513-791-9393  
888-825-1917  
Fax. 513-353-4454  
sales@quikpave.com